



TCC-330 LAMINATOR PARTS MANUAL

DATE: 02/20/2017

DRAWING NO.	PART NO.	DESCRIPTION	DRAWING NO.	PART NO.	DESCRIPTION
001	3LM-B1	CONTROL PANEL	030	3LM-D21	TRANS AXILE
002	3LM-B2	GEAR	031	3LM-D31	FIXED PLATE
003	3LM-B3	BUSH	032	3LM-D23	PAD
004	3LM-B4	GEAR	033	3LM-D24	SPRING
004-1	3LM-B4-1	GEAR	034	3LM-D25	SPRING
005	3LM-B6N	FRONT ROLLER (LOWER)	035	3LM-D26	SPRING PAD
006	3LM-B5N	FRONT ROLLER (UPPER)	035-1	3LM-D27	DEPRESS PLATE
007	3LM-B7N	REAR ROLLER (UPPER)	035-2	3LM-D28	FIXED PLATE
007-1	3LM-B8N	REAR ROLLER (LOWER)	036	3LM-P1	HEATER
008	3LM-B7	KNOB	037	3LM-P2	HEAT-RESIST FORM
009	B-9	FOOT PAD	038	3LM-P3	PCB
009-1	3LM-B10	MARK	039	3LM-P4	SOCKET
010	3LM-D1	BASE	040	3LM-P5	POWER CORD
010-1	3LM-D4	TOP COVER	041	3LM-P6A	SYNCHRONOUS MOTOR
010-2	3LM-D7	TOP INNER COVER	042	3LM-P7	CUT-OFF FUSE
018	3LM-D9	REAR PLATE	043	3LM-P8	SWITCH
019	3LM-D10	REAR DEPRESS PLATE	043-1	3LM-P8A	SWITCH
020	3LM-D11	BARCKET (L)	044	3LM-P11-3	VR
021	3LM-D12	BARCKET (R)	044-1		LED LAMP
022	3LM-D13	HOOK PLATE (R)	044-2		LED LAMP SET
023	3LM-D14	HOOK PLATE (L)	045	3LM-P10	SERSOR WIRE
024	3LM-D15	MOTOR RACK	046	D226A	LINE A
025	3LM-D16	POWER RACK	047	D226B	LINE B
026	3LM-D17	HEAT-RESIST PLATE	048	D226C	LINE C
027	3LM-D18	HEAT PLATE	049	D266D	LINE D
028	3LM-D19	SUPPORT PLATE	050	3LM-F	FUSE (8A)
029	3LM-D20	AXLE			